

Platen Cleaning

Cleaning the HandPunch platen when needed is important to keep the HandPunch operating. Dirt on the platen may cause disturbance to the camera function.

The best way to clean the platen is to use regular window cleaner and a clean piece of cloth. In addition, the use of Isopropyl Alcohol 99% is OK.

Please avoid using any of these fluid and they may affect the platen ability to reflect light in proper direction:

- Acetone and Acetate
- Methanol and Ethanol

If employees are using hand cream containing Methanol and/or Ethanol it must be used after using the HandPunch in order to protect the platen.

For more information please visit our website at www.handreader.com

Schlage Biometrics
Product Management